




ITEM #		Perimeter Piers
23506	6" Perimeter Pier - CP	 <p>CP Perimeter Piers are rated at 3000lb made from 12 gauge steel and painted with a rust preventive coating</p>
23508	8" Perimeter Pier - CP	
23510	10" Perimeter Pier - CP	
23512	12" Perimeter Pier - CP	
23514	14" Perimeter Pier - CP	
23516	16" Perimeter Pier - CP	
23518	18" Perimeter Pier - CP	
23520	20" Perimeter Pier - CP	
23522	22" Perimeter Pier - CP	
23524	24" Perimeter Pier - CP	
23526	26" Perimeter Pier - CP	
23528	28" Perimeter Pier - CP	
23530	30" Perimeter Pier - CP	
23532	32" Perimeter Pier - CP	
23534	34" Perimeter Pier - CP	
23536	36" Perimeter Pier - CP	
23054	36" Perimeter Pier - Straight	
23083	Perimeter Jack 30" – 36" w/o Plate	

ITEM #		Primary Support Columns (PSC)
<p>The FoundationWorks Primary Support Columns (PSC) consist of the proper number of multi-hazard support columns, positioned according to FoundationWorks installation specifications to optimize foundation performance.</p>		
23147	Magnum Pier "A"	
23148	Magnum Pier "B"	
23149	Magnum Pier "C"	

ITEM #		Pier Heads
23060	L Top 5"	
23061	Flat Top 5" w/holes	
23029	Saddle Top 5"	
23062	Saddle Top 10"	
23063	Bolt on Top 5" Locking	
23103	Pier Head 10 L Top ATR	
23077	Pier Head Bolt Top 5 Stm	
23104	Pier Nut	
23144	Pier Strap - 15" x 2" X3/16"	
23146	Pier Base Strap	

ITEM #		Norco Jacks
22020	Jack 12 Ton Short Bottle	
22022	Jack 20 Ton Bottle	
22150	Jack 12 Ton Long Bottle	
23054	Perimeter Jack - 30"	
22462	Jack - Air/Hydraulic 20 Ton Norco	
22463	Jack - Air/Hydraulic 12 Ton Norco	
23081	Perimeter Jack - 24" (No Plate)	
22188	Jack Jet 12 ½ Ton - Long	
22151	Jack Jet 12 ½ Ton - Short	